

# INSTALLING YOUR CELLULAR BLINDS



It's as easy as 1-2-*Me*


## Important Notes

- Please check that all parts and hardware have been supplied before you begin to install your new Cellular Blind.
- Do not lower the blind until it has been fully installed.
- Ensure that the blind is installed level for correct operation.

## Positioning Blind

As per your order, determine the correct fitting location of the mounting brackets and mark where you are going to install the brackets.

- Inside the window frame (Recess) or;
- On the window frame or wall (Face)




## Installing Mounting Brackets


<p>1-3/4" Bracket</p>	<b>RECESS FIT</b>	<p>i. Pencil mark the mounting screw holes at the top of the bracket.</p> <ul style="list-style-type: none"> <li>• Drill holes at the pencil-marked locations.</li> <li>• Position the brackets about 1/2" to 2" from each end of head rail of shade. Avoid placing brackets over the spring box or cord spool.</li> </ul>	<p>ii. Secure the brackets with the mounting screws provided.</p> <ul style="list-style-type: none"> <li>• When mounting brackets on wall board or plaster, use the wall anchors provided.</li> </ul>
	<b>FACE FIT</b>	<p>i. Pencil mark the mounting screw holes at the back of the bracket.</p> <ul style="list-style-type: none"> <li>• Drill holes at the pencil-marked locations.</li> <li>• Use level at top of brackets to ensure straight alignment. Shade needs to be level for proper operation.</li> </ul>	<p>ii. Secure the brackets with the mounting screws provided.</p> <ul style="list-style-type: none"> <li>• When mounting brackets on wall board or plaster, use the wall anchors provided.</li> </ul>

## Attaching the Blind To Brackets

### ABS bracket




i. Lift the head rail into position so that the front edge of each bracket is sliding under the inner front edge of the headrail.




ii. Push the head rail upwards until the flexible tab at the bottom of each bracket snaps onto the back of the headrail.

### Metal bracket




i. Lift the head rail into position so that the front edge of each bracket is sliding under the inner front edge of the headrail.




ii. Push the head rail upwards until the flexible tab at the bottom of each bracket snaps onto the back of the headrail.

**Note:** Make sure that the front side of the shade is facing toward the room and the back side of the shade with the support strips is facing the window pane.

## Operating the Blind



Disengage the cordlock by pulling the lift cord toward the center of the shade to raise or lower shade.




Raise or lower shade to desired position and let go. Cordlock will automatically engage.

## Child Safety Instructions

For Blinds With Cord Control

### WARNING

- The cord cleat must be fitted to ensure child safety and to comply with regulations.
- The cleat is to be positioned at least 1600mm above floor level, as a child is capable of unwinding a cord from a cleat.
- Use two screws to attach each cleat to the wall. Do not use tape or glue to attach the cleat.
- Installed cleat must be able to withstand a 7 Newton load for 10 seconds in all directions.
- Wrap excess cord around the cleat every time the blind is raised/lowered, to prevent child strangulation.
- The cord must not form a loop longer than 220mm and should be wound entirely around the cleat every time.



### WARNING – ALL WINDOW COVERINGS WITH CORD OR CHAIN

To avoid creating a possible strangulation hazard for children, the corded or chained internal window covering must be installed in such a way that a loose cord or chain cannot form a loop 220mm or longer at a height of less than 1600mm above floor level.

- A cord/chain guide may be installed lower than 1600mm above floor level if the cord/chain is sufficiently secured or tensioned to prevent a loop 220mm or longer being formed.
- If a cord/chain guide is installed lower than 1600mm above floor level, it must be designed to prevent a child from being able to remove the cord/chain.
- If a cleat is used to secure the cord, it must be at least 1600mm above floor level because a child is capable of unwinding a cord from a cleat.